


# alfresia



## **3 x 3mtr Pop Up Gazebo with 4 Side Walls**

PLEASE READ AND KEEP THESE INSTRUCTIONS FOR FUTURE USE

**SAP Code: JU03600001**

For further assistance, other products and more, join  
us at:

Website: [www.alfresia.co.uk](http://www.alfresia.co.uk)



Instagram: [@alfresiauk](https://www.instagram.com/alfresiauk)

Facebook: [www.facebook.com/alfresia](https://www.facebook.com/alfresia)


Thank you for choosing our Alfresia 3 x 3m Pop Up Gazebo with 4 Side Walls. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact our customer service team on the details provided on the back page of this manual.

### Components Supplied


Please check the list of supplied items which correspond to the numbered diagrams below:



C X 1



D X 2



E X 1



F X 8



G X 4



H X 1

Please ensure that you have received all of the above items and check for any damages before use. If you find any damages, please contact our customer services department.

## WARNING:

- Keep all flame and heat sources away from the fabric.
- Always read and follow the instructions before use. Be cautious to avoid pinching your hands or fingers in any of the moving parts as the frame opens and closes.
- The gazebo is designed to provide shade only. Do not use this gazebo in strong wind and rain. Wind and rain can damage the gazebo and could result in injury to you and others.
- Please note this will take 2 people to construct.

## Assembly Instructions

### **IMPORTANT: DO NOT USE EXCESSIVE FORCE DURING ANY PART OF SET UP**


1. Stand frame upright. Starting at the corners, each person should stand on opposite sides, grasp the two outer legs, slightly lift the frame off the ground and step backward, stopping at full arm's length.




2. Unfold the fabric canopy pack, place the fabric top over the top frame. Use the Velcro pads to secure each corner of the cover to the frame under the plastic caps.



3. Each person should then grasp the bottom of the middle frame section (cross beams). Lift slightly and slowly walk backwards until the frame has full extended. Be careful not to trap your fingers or pull backwards too hard as this may result in the cross beams becoming warped.




4. Engage the slider at each corner by pushing up the piece with one hand whilst holding down the top of the leg with the other hand. Repeat this process on the remaining corners.



5. To secure the fabric top to the frame, wrap the Velcro loops around the roof tubes and cross beams.



6. Pull down the inside valances to cover the beam tubes and Velcro the adjacent valances together for a cleaner look.



7. Lift the two adjacent outer legs and pull out the inner legs gently until the spring loaded snap button pops into position. Repeat this process on the remaining legs.



### Assembly Notes

- Assemble on a flat, level surface or marking the ground
- Do not use if any parts are missing, damaged or worn
- Do not use if any of the fixings or fittings are not secure
- Always place the Gazebo on a flat, level surface before use
- Always use the product for its intended purpose. Misuse of the product could cause injury

### Care & Maintenance

- Periodically check that all of the screws and fixings are secure and tighten if necessary
- Sponge Clean only with a damp cloth and a small amount of mild detergent. Do not Bleach.

## Guarantee

Our products are guaranteed for a period of 2 years from the date of purchase. Products that develop a fault within this period are covered by our warranty and we will replace defective parts, or where not available the whole product. The warranty does not apply to any defect in the goods arising from fair wear and tear, wilful damage, accident, negligence by you or any third party, use otherwise than as recommended by us, failure to follow our instructions, any alteration or repair carried out without our approval or has been the subject of commercial use. Your statutory rights remain unaffected, in particular any rights you have under the Consumer Rights Act 2015.

If you have a problem with your product within this warranty period please contact our customer services team.

In the event of changes to the specification of a product and we are not able to replace parts, we will replace the whole product within the 2 year guarantee period

For products that fall outside of the 2 year guarantee, we will endeavour to provide spare parts to purchase for as many of the replaceable parts as possible, but cannot foresee specification changes or upgrades to products or parts outside of the initial 2 year period.

### Customer Services:

If you would like further advice or information on your product, ensure you have the SAP code ready and please get in touch with us at Alfresia on the contact options below:

**SAP Code:** JU03600001

**Phone:** 0330 002 1600 (Mon – Fri 9am to 5pm)

**Email:** [support@alfresia.co.uk](mailto:support@alfresia.co.uk)

**Address:** Alfresia, Vale Mill (Rochdale) Ltd, Robinson Street, Rochdale, OL16 1TA