


alfresia



BBQ Gazebo

PLEASE READ AND KEEP THESE INSTRUCTIONS
FOR FUTURE USE

SAP Code: JT06520207



Two person assembly

For further assistance, other products and more, join us at:

Website: www.alfresia.co.uk

Instagram: [@alfresiauk](https://www.instagram.com/alfresiauk)

Facebook: www.facebook.com/alfresia

Thank you for choosing our Alfresia BBQ Gazebo. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact our customer service team on the details provided on the back page of this manual.

SAFETY INSTRUCTIONS



WARNING:



















- The canopy is fire resistant only. Do not leave active flame, heat sources or cooking apparatus unattended inside the Gazebo.
- Carelessness causes fire. Always take appropriate safety precautions when heat sources are in use, fires are lit or cooking is taking place inside the Gazebo.
- The gazebo is designed to provide shade only. Do not use or leave erected in strong wind and rain. Wind and rain can damage the gazebo and could result in injury to you and others
- Familiarise yourself with the instructions and check all components for damage before erecting and dismantling the Gazebo
- Erecting the Gazebo will require working from height. Use appropriate equipment, safe working practices and do not work from height if you feel unwell.
- At least two people are required to erect and dismantle the Gazebo. Erection alone could cause injury to persons or damage to the Gazebo or property
- Be careful to avoid pinching your hands or fingers in any of the parts during construction .
- Do not use excessive force while erecting or dismantling the Gazebo as this could cause damage
- Always secure the Gazebo with the pegs after assembly for stability
- Always use the product for its intended purpose. Misuse of the product could cause injury.

Assembly Notes

- Assemble on a soft, clean surface to avoid damaging or marking the pieces
- Do not use if any parts are missing, damaged or worn
- Do not use if any of the fixings or fittings are not secure
- Always place the product on a flat, level surface before use

Components Supplied

Please check the list of supplied items which correspond to the numbered diagrams below:


A		2PCS
A1		2PCS
B		2PCS
C		2PCS
D		4PCS
E		4PCS
F		1PC
G		2PCS
H		4PCS
I		4PCS
J		4PCS
K		1PC
L		1PC
M	 M6×15	36PCS
N	 M6×20	4PCS
O		1PC
P		1PC
Q		8PCS

Please ensure that you have received all of the above items and check for any damages before use. If you find any damages, please contact our customer services department.


Assembly Instructions

IMPORTANT: DO NOT USE EXCESSIVE FORCE DURING ANY PART OF SET UP


1. Assemble the four legs (2 x A, 2 x A1) by securing the "U" shaped bracket (4 x I) to the top using the smaller screws (4 x M). Then slide the bottom of each leg onto each foot (4 x J).




2. Attach the frame end pieces (2 x B) and side pieces (2 x C) to the legs (2 x A & 2 x A1) using the smaller screws (16 x M) to form the frame. Ensure that the mounting holes for the shelf brackets on each leg face inwards.




3. Assemble the four canopy supports by joining a canopy and vent support piece (1 x D) and a canopy end piece (1 x E). Fit the lower of the two top ends of each support (D) into the top bracket (F) so that the vent supports protrude above the level of the bracket and the canopy supports curve downwards. Fix the assembled canopy structure to the "U" shaped brackets (I) on each corner of the frame using the longer screw and nut (4 x N).




4. Place the canopy (K) over the frame and fit the end piece of each canopy support (E) into the pocket of each corner of the canopy to secure. Ensure the vent supports protrude from the hole in the centre of the canopy (K).




5. Attach the vent (L) to the protruding vent supports by fitting the end of each vent support into the pocket on each corner of the vent to secure.



6. Attach the shelf brackets (2 x H) to the underside of each shelf (2 x G) using the shorter screws (8 x M).



7. Attach the shelves (2 x G) to each end of the Gazebo frame using the shorter screws (8 x M). Secure the feet (4 x J) to the ground using the pegs (8 x Q) to ensure it remains stable in use.



Care & Maintenance

- Periodically check that all of the fittings and fixings are secure and tighten if necessary
- Sponge Clean the frame with a damp cloth and a small amount of mild detergent.
- Clean the fabric according to the care label instructions, hang and leave to dry naturally. Dirt and debris can be removed gently with a soft brush.

Storage

- Always dry the Gazebo before repacking for storage
- Remove soil and dirt from the pegs, fabric and frame before storing
- Store in a cool, dry place away from direct sunlight

Guarantee

Our products are guaranteed for a period of 2 years from the date of purchase. Products that develop a fault within this period are covered by our warranty and we will replace defective parts, or where not available the whole product. The warranty does not apply to any defect in the goods arising from fair wear and tear, wilful damage, accident, negligence by you or any third party, use otherwise than as recommended by us, failure to follow our instructions, any alteration or repair carried out without our approval or has been the subject of commercial use. Your statutory rights remain unaffected, in particular any rights you have under the Consumer Rights Act 2015.

If you have a problem with your product within this warranty period please contact our customer services team.

In the event of changes to the specification of a product and we are not able to replace parts, we will replace the whole product within the 2 year guarantee period

For products that fall outside of the 2 year guarantee, we will endeavor to provide spare parts to purchase for as many of the replaceable parts as possible, but cannot foresee specification changes or upgrades to products or parts outside of the initial 2 year period.

Customer Services:

If you would like further advice or information on your product, ensure you have the SAP code ready and please get in touch with us at Alfresia on the contact options below:

SAP Code: JT06520207

Phone: 0330 002 1600 (Mon – Fri 9am to 5pm)

Email: support@alfresia.co.uk

Address: Alfresia, Vale Mill (Rochdale) Ltd, Robinson Street, Rochdale, OL16 1TA