

alfresia



Java Conservatory Chair

PLEASE READ AND KEEP THESE INSTRUCTIONS FOR FUTURE USE

SAP Code: JC10202011

For further assistance, other products and more, join
us at:

Website: www.alfresia.co.uk



Instagram: [@alfresiauk](https://www.instagram.com/alfresiauk)

Facebook: www.facebook.com/alfresia

Thank you for choosing our Alfresia Java Conservatory Chair. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact our customer service team on the details provided on the back page of this manual.

Components Supplied


Please check the list of supplied items which correspond to the numbered diagrams below:




Please ensure that you have received all of the above items and check for any damages before use. If you find any damages, please contact our customer services department.

Assembly Instructions


1. Assemble the main seat of the unit using pieces (A), (B), (C) and (D) and the (E) fixture and Allen key provided as shown in the diagram below. Insert the wooden dowels (G) into the screw holes once you have finished construction of the seat:



2. After this, place the seat pad (H) onto the supports as shown in the diagram below:



3. Your assembled product should look as below and you can now place your conservatory cushions onto the frame:



Assembly Notes

- Assemble on a soft, clean surface to avoid damaging or marking the pieces
- Do not use if any parts are missing, damaged or worn
- Do not use if any of the fixings or fittings are not secure
- Always place this (product name) on a flat, level surface before use
- Always use the product for its intended purpose. Misuse of the product could cause injury

Care & Maintenance

- To clean, wipe down the surfaces with a soft damp cloth and a small amount of mild detergent. Do not immerse in water.
- Periodically check that all of the screws and fixings are secure and tighten if necessary

Guarantee

Our products are guaranteed for a period of 2 years from the date of purchase. Products that develop a fault within this period are covered by our warranty and we will replace defective parts, or where not available the whole product. The warranty does not apply to any defect in the goods arising from fair wear and tear, wilful damage, accident, negligence by you or any third party, use otherwise than as recommended by us, failure to follow our instructions, any alteration or repair carried out without our approval or has been the subject of commercial use. Your statutory rights remain unaffected, in particular any rights you have under the Consumer Rights Act 2015.

If you have a problem with your product within this warranty period please contact our customer services team.

In the event of changes to the specification of a product and we are not able to replace parts, we will replace the whole product within the 2 year guarantee period

For products that fall outside of the 2 year guarantee, we will endeavour to provide spare parts to purchase for as many of the replaceable parts as possible, but cannot foresee specification changes or upgrades to products or parts outside of the initial 2 year period.

Customer Services:

If you would like further advice or information on your product, ensure you have the SAP code ready and please get in touch with us at Alfresia on the contact options below:

SAP Code: JC10202011

Phone: 0330 002 1600 (Mon – Fri 9am to 5pm)

Email: support@alfresia.co.uk

UK Address: Alfresia, Vale Mill (Rochdale) Ltd, Robinson Street, Rochdale, OL16 1TA

EU Address: Alfresia, Delu-Ako Minky GmbH, Hauptstraße 103, 53619, Rheinbreitbach, Germany